# PRINT IP CONFIGURATION REPORT ON IX5 AND IX7

1. Ensure that labels are loaded in the Mailing Machine before printing the report.

2. Press ☰ and select **#14 Supervisor**

3. The Login screen is displayed.

4. Type the supervisor PIN code 09430 and press [OK].

5. The supervisor Main menu is displayed.

6. Select **#2 Reports**

7. Use the arrow keys to navigate until you locate the **IP Configuration Report** and select it.

Select Report	⊕

5	Daily Usage
6	Monthly Usage
7	Machine Configuration
8	Single Account
9	IP Configuration Report
10	Proxy Configuration

Cancel   Select